

12-3-13
PHYSICS II

CH29
CH30

HW ASSIGNED
WWW.MAPPHYSICS.COM

Review CH30 via HW REVIEW (online)

RETURN QUIZ 8, 9, LAB(S).


DISCUSS QUIZ 10 ON CH29, 30, 31, 32(?)

CH30 REVIEW VIA SHORT SURVEY

Excitation: PHOTON IS ABSORBED.
(HIGHER ENERGY γ ; ELECTRON DISPLACED FROM $n=1$ TO $n=2$)


h = PLANCK'S CONSTANT
 f = FREQUENCY

$$hf = E_2 - E_1 = \text{PHOTON ENERGY}$$



$$E_2 > E_1$$

Emission: electron displaced from HIGHER TO LOWER ENERGY.



$$\text{photon energy} = hf = E_2 - E_1$$


f = light frequency

h = Planck's constant



Note: We pretend light has a particle called photon.

Example of an *
Excited Atom:

$n=2$ (vacant)



"normal"
unexcited
ATOM.




excited
ATOM.

$n=1$ (empty)

* Photon WAS
ABSORBED.


Note: Photon Energy = hf
Photon speed = $c = 3 \times 10^8 \frac{m}{s}$

 $c = 3 \times 10^8 \frac{m}{s}$
IN A VACCUUM.

f = frequency of
light wave
associated
with photon,
which is
a particle.


Hint: # 10, HW CH 30: WHICH
COLOR HAS LARGEST f ?

FLUORESCENT LIGHT



UV PHOTON
EXCITES ELECTRON
FROM $n=1$ TO HIGH
LEVEL. THEN ELECTRON
THEN DROPS TO
INTERMEDIATE LEVEL - EMITS
PHOTON OF FLUORESCENT LIGHT

SPECTRAL lines:



MISSING HYDROGEN FREQUENCIES
↓




p 535, fig 30.9

CH 31 QUANTUM THEORY

PHOTOELECTRIC EFFECT;

photon = particle of light.



1 PHOTON FOR EACH ELECTRON

Explained in fig 31.3

$$hf = KE + \phi$$


ENERGY BARRIER OVERCOME TO ESCAPE

analogy from CH. 7:

LIKE POTENTIAL ENERGY (P.E.)

WORK FUNCTION


P.E. is from attraction of ball to earth.
 ↓
 P.E. needed to escape well.



$$\text{Energy} = \frac{1}{2}mv^2 + mgh$$


De Broglie


IF light can be thought of
as a WAVE OR PARTICLE
(photon); matter can
ALSO be thought of as
a WAVE.



CH 31 SUMMARY: light is
composed of quanta (particles)
called photons.

Fig 31.6 → see fig 29.18






Electron
waves also
exhibit
interference
patterns

electron counts
show wave pattern
like fig 29.18
(see fig 31.11)

ch 31 video:


Modern physics (CN31)

CN31 MEILS Bohr hypothesis



CH 31

Here is OLD idea disproved by Bohr:




could have
any energy
JUST LIKE
planet orbiting
about sun.

↑
NOT TRUE for ATOMS.
only discrete orbits
allowed (in CH 31)

Here's how
DeBroglie
combined "wave"
model with the
so called PARTICLE
model of Bohr, who
believed discrete orbits.

DeBroglie: ONLY
STANDING WAVES FIT
INTO ORBIT.

fig 32.11
OR
fig 32.12.



$n = 4$ ENERGY level $\rightarrow n = 4$

Newton's Third Law

You may have learned this statement of Newton's third law: "To every action there is an equal and opposite reaction." What does this sentence mean?

Unlike Newton's first two laws of motion, which concern only individual objects, the third law describes an interaction between two bodies. For example, what if you pull on your partner's hand with your hand? To study this interaction, you can use two Force Sensors. As one object (your hand) pushes or pulls on another object (your partner's hand) the Force Sensors will record those pushes and pulls. They will be related in a very simple way as predicted by Newton's third law.

The *action* referred to in the phrase above is the force applied by your hand, and the *reaction* is the force that is applied by your partner's hand. Together, they are known as a *force pair*. This short experiment will show how the forces are related.




Figure 1


OBJECTIVES

- Calibrate two Force Sensors.
- Observe the directional relationship between force pairs.
- Observe the time variation of force pairs.
- Explain Newton's third law in simple language.

MATERIALS

Power Macintosh or Windows PC
LabPro or Universal Lab Interface
Logger Pro
two Vernier Force Sensors


500-g mass
string
rubber band



PRELIMINARY QUESTIONS

1. You are driving down the highway and a bug splatters on your windshield. Which is greater: the force of the bug on the windshield, or the force of the windshield on the bug? **SAME** (1)
2. Hold a rubber band between your right and left hands. Pull with your left hand. Does your right hand experience a force? Does your right hand apply a force to the rubber band? What direction is that force compared to the force applied by the left hand? (1)

\vec{F} is right
BR




Experiment 11

3. Pull harder with your left hand. Does this change any force applied by the right hand?
4. How is the force of your left hand, transmitted by the rubber band, related to the force applied by your right hand? Write a rule, in words, for the force relationship.

PROCEDURE

1. Connect the two Student Force Sensors or the two Dual-Range Force Sensors to Channels 1 and 2 on the LabPro or Universal Lab Interface. If you are using Force Probes, connect them to PORT 1 and PORT 2.
2. Open the Experiment 11 folder from *Physics with Computers*. Then open the experiment file that matches the force sensors you are using. If your sensor has a range switch, set it to 50 N. One graph will appear on the screen. The vertical axis will have force scaled from -20 to 20 N. The horizontal axis has time scaled from 0 to 10 s.
3. Force Sensors measure force only along one direction; if you apply a force along another direction, your measurements will not be meaningful. The Dual Range Force Sensor and the ULI Force Probe respond to force directed parallel to the long axis of the sensor. The Student Force Sensor responds to forces applied to the hook along the line (between the ends of the "U" formed by the sensor).
4. Since you will be comparing the readings of two different Force Sensors, it is important that they both read force accurately. In other words, you need to *calibrate* them. To calibrate the first sensor,
 - a. Choose Calibrate from the Experiment menu. Click on the port of the first Force Sensor so the port is highlighted, and if necessary, on the port of the second Force Sensor so it is not highlighted. Click on the button.
 - b. Remove all force from the first sensor and hold it vertically with the hook pointed down. Enter a 0 (zero) in the Value 1 field, and after the reading shown for Input 1 is stable, click . This defines the zero force condition.
 - c. Hang the 500-g mass from the sensor. This applies a force of 4.9 N. Enter 4.9 in the Value 2 field, and after the reading shown for Input 1 is stable, then click .
 - d. Click to complete the calibration of the first Force Sensor.
5. Repeat the process for the second Force Sensor with one important exception: Instead of entering 4.9 for the Value 2 field, enter -4.9. The minus sign indicates that for the second sensor a pull is negative. For this activity it is helpful to set up the two Force Sensors differently, since later you will have the sensors positioned so that a pull to the left will generate the same sign of force on each sensor.
6. You will be using the sensors in a different orientation than that in which they were calibrated. Zero the Force Sensors to account for this. Hold the sensors horizontally with no force applied, and click . Click to zero both sensors. This step makes both sensors read exactly zero when no force is applied.
7. Click to take a trial run of data. Pull on each Force Sensor and note the sign of the reading. Use this to establish the positive direction for each sensor.
8. Make a short loop of string with a circumference of about 30 cm. Use it to attach the hooks of the Force Sensors. Hold one Force Sensor in your hand and have your partner hold the

$|\vec{F}_{BL}|$ is $(+)$
LARGER




other so you can pull on each other using the string as an intermediary. Be careful to apply force only along the sensitive direction of your particular Force Sensor.

- Click **Collect** to begin collecting data. Gently tug on your partner's Force Sensor with your Force Sensor, making sure the graph does not go off scale. Also, have your partner tug on your sensor. You will have 10 seconds to try different pulls. Choose Store Latest Run from the Data menu.
- What would happen if you used the rubber band instead of the string? Would some of the force get "used up" in stretching the band? Sketch a prediction graph, and repeat Steps 8-9 using the rubber band instead of the string.

ANALYSIS

6 points



1. Examine the two data runs. What can you conclude about the two forces (your pull on your partner and your partner's pull on you)? How are the magnitudes related? How are the signs related?

1

2. How does the rubber band change the results—or does it change them at all?

1

While you and your partner are pulling on each other's Force Sensors, do your Force Sensors have the same positive direction? What impact does your answer have on the analysis of the force pair?

NO; OPPOSITE DIRECTIONS TOWARD CENTER

1

4. Is there any way to pull on your partner's Force Sensor without your partner's Force Sensor pulling back? Try it.

NO

2

5. Reread the statement of the third law given at the beginning of this activity. The phrase *equal and opposite* must be interpreted carefully, since for two vectors to be equal ($\vec{A} = \vec{B}$) and opposite ($\vec{A} = -\vec{B}$) then we must have $\vec{A} = \vec{B} = 0$; that is, both forces are always zero. What is really meant by *equal and opposite*? Restate Newton's third law in your own words, not using the words "action," "reaction," or "equal and opposite."

EQUAL MAGNITUDES
OPPOSITE DIRECTIONS

1

6. Re-evaluate your answer to the bug-windshield question.

BUG FEELS SAME FORCE AS WINDOW BUT EXPERIENCES MORE DAMAGE

EXTENSIONS

- Fasten one Force Sensor to your lab bench and repeat the experiments. Does the bench pull back as you pull on it? Does it matter that the second Force Sensor is not held by a person?
- Use a rigid rod to connect your Force Sensors instead of a string and experiment with mutual pushes instead of pulls. Repeat the experiments. Does the rod change the way the force pairs are related?